


Slip 'N Tuck Knitting Sequence

Stitch Pattern: **KIN702**

NOTE: You must be familiar with the settings for YOUR machine to tuck and slip.

You cannot tuck 2 stitches side by side. When working Knit it Now Slip 'N Tuck stitch patterns, be sure you are not tucking if 2 needles are selecting side by side. (Slip Stitch does not have this limitation)



Tuck in one direction – then slip in the opposite direction

BROTHER	STUDIO/SILVER
Tuck buttons = TUCK (one direction)	Tuck: CAM Lever = T Russel Levers II (one way) Side Levers ▼ (one way)
Part buttons = SLIP (opposite direction)	SLIP: CAM Lever = S Russel Levers II (opposite way) Side Levers ▼ (opposite way)